

The Point Apartments

Operation Instruction for Comelit Audio/Video Intercom System



Entrance Panel

To call an apartment from an entrance panel dial the apartment number then press "Bell" button to initiate call.

Entrance Panel
Model: iKall


Monitor Features:

1. Answer Key
2. Speaker
3. Door Unlock & Lift Release Key
4. LCD Colour Touch Display
5. Microphone
6. Camera
7. Privacy Key LED
8. Message Menu Key

Pressed - allows access to the messages section.

Lit Steadily - video memory / absent message active. **Flashing** - new message waiting.

9. Not Used



Apartment Monitor
Model: Tuscany 6804W

Upon receiving a call from an intercom entrance panel a ring tone will be emitted from the apartment monitor and a video image will automatically appear. You may answer the call by pressing the Answer Key "1". To grant your visitor access into the building and to your apartment floor level press the Door Unlock & Lift Release Key "3", this function will unlock the entry door for approx. 5 seconds and release the lift for approx. 180 seconds (this function will de-secure the floor selection button relevant to your floor only within the lift car).

Rev: A